



1

Remove one original wheel nut/wheel bolt from each wheel of your vehicle (1). When changing a wheel at a later stage, always **remove** the wheel lock as the **first nut/bolt** and **install** it as the **last nut/bolt**.



3


Using the key provided and a torque wrench, tighten each McGard wheel lock with the torque specified in your vehicle's manual. Apply axial pressure on the torque wrench to prevent the key provided from slipping or jamming. Turn the wheel by hand to check whether it rotates freely and without impediment.



2


Before installing the wheel lock, please always check that the McGard wheel lock has the same thread, seat and shaft/overall length as the original nut/bolt!

Install a McGard wheel lock by hand on each wheel. Make sure that the key pattern is firmly and securely engaged into the designated lock pattern.



4

Do not use an impact spanner as this can damage the McGard wheel lock/key and your vehicle. After the first 50 km, please retighten the McGard wheel lock to the torque specified in your vehicle's manual using a torque wrench. So that you can access your key in the event of a wheel change, we recommend that you keep your key, the original nuts/bolts for your vehicle, and these installation instructions (with your personal code number) in the resealable packaging in a safe place in your vehicle.



!

Free registration under:

www.mcgard.de/kundenservice

If you have lost your key or code card, we can use this registration to provide you with a replacement one.

Registration by E-mail:

cs@mcgard.de

We'll need your personal code number and address.

Reordering a key:

Simply go to our web shop under shop.mcgard.de where you can quickly and easily order a new key.

Orders by E-mail:

cs@mcgard.de

We'll need your key code, name, address and Payment method. Prices are subject to change without notice.

Need assistance?

If you have any questions, our customer services will be pleased to help you: Monday till Friday 08:00 am to 05:00 pm.

Freephone hotline:

00800 25 99 34 00



shop.mcgard.de